DIPC-B1222.1.76.220720

Release Notes

Zhejiang Uniview Technologies Co., Ltd

DIPC-B1222.1.76.220720

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure

forDIPC-B1222.1.76.220720.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

3
3
3
3
3
4
4
4
4
5
5
5
5

1 Version Information

1.1 Version Number

DIPC-B1222.1.76.220720

1.2 Release History

Table1Released versions

Version No.	Basic Version No.	Released On	Remarks
DIPC-B1222.1.76.220720	DIPC-B1222.1.71.220329	2022-08-04	Improved release

Table2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR	B3111.31.51.220121/ B3610.21.13.201207

1.3 Version Mapping Table

Table3Product models and corresponding versions

Product Series	IPC Series		
Series	IPC2124LB、IPC324LB、IPC3614LB、IPC-B125、IPC-T125、IPC-D125		
	IPC2124LB series:		
Models	IPC2124LB-SF28KM-G、IPC2124LB-SF40KM-G		
	IPC324LB series:		
	IPC324LB-SF28K-G、IPC324LB-SF40K-G		
	IPC3614LB series:		
	IPC3614LB-SF28K-G、IPC3614LB-SF40K-G		
	IPC-B125 series:		
	IPC-B125-APF28、IPC-B125-APF40、IPC-B125-APF28-SC、IPC-B125-APF40-SC		
	IPC-T125 series:		
	IPC-T125-APF28、IPC-T125-APF40、IPC-T125-APF28-SC、IPC-T125-APF40-SC		
	IPC-D125 series:		
	IPC-D125-PF28、IPC-D125-PF40、IPC-D125-PF28-SC、IPC-D125-PF40-SC		
Target file name	DIPC-B1222.1.76.220720.zip		

2 Feature Change Description

D2005SP76(DIPC-B1222.1.76.220720):

None

D2005SP71(DIPC-B1222.1.71.220329):

None

D2005SP70(DIPC-B1222.1.70.220317):

ltem	Feature	Description
Newly added features	Mandatory information	By default, user must fill in his/her mobile phone number or email address when logging in to the Web interface for the first time.
Improved features	None	None
Deleted features	None	None

3 Version Upgrade Description

None.


4 Version Upgrade Procedure

4.1 Upgrade Overview

4.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure1Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.


4.1.2 Version Upgrade Modes

You can upgrade through the Web.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click Setup>Maintenance>Device Maintenance. The Device Maintenance page is displayed.



- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_D1222-XXXXX.zip, and then click **Open.**
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

5 Version Upgrade Disclaimer

- By setting or installing this program in any way you agree to all of the following terms and conditions. Your
 downloading or using the program means you acknowledge your full understanding and acceptance of the
 following terms and conditions. If you do not agree to any of the following terms, you shall not use the program
 and you must cease installing and delete the program immediately.
- 2. The upgrade program is only applicable to the intended regions and product models. Before upgrade or update, please read the release notes carefully to make sure the program is applicable to your region and product model. You will be fully liable and responsible for all the consequences of device abnormality and related maintenance

- costs caused by your improper operations.
- 3. Uniview owns or is legally authorized to own all rights and IPRs (Intellectual Property Rights) of the program and the supplied release notes.
- 4. Software upgrades are for the optimization of product functions and do not mean there is defect.
- 5. You must strictly follow instructions in the release notes during the upgrade process, otherwise you are responsible for the possible consequences and related maintenance costs.
- 6. You shall not engage in any of the following activities, otherwise you would be liable for infringement and responsible for any adverse consequences arising therefrom.
- 6.1 Copy the program (exclude the reasonable and necessary copies for internal backups);
- 6.2 Exclude this statement when using the program or transfer the program to any third party;
- 6.3 Modify the program or its derivatives;
- 6.4 Reverse engineer, decompile or disassemble this program.
- 7. The program is only intended for authorized users. Its architecture, organization and source code are valuable trade secrets and confidential information owned by Uniview and its authorized parties. You agree not to provide or disclose any confidential information contained in or derived from the software to any third party. No part of this document may be excerpted, reproduced, or distributed in any form by any entity or individual without written consent from our company.