

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for

IPC_E5101-B5012P07D1603C31/IPC_G6101-B5010P30D1607C28/

IPC_G6102-B5013P12D1611C11/IPC_G6102-B5013P61D1611C05/

IPC_HCMN2103-B0016P12D1611C11/IPC_HCMN2105-B0005P12D1611C11/

IPC_Q1201-B5018P12D1611C11/IPC_5202-F5026P12D1611C11.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

- 1 Version Information..... 3
 - 1.1 Version Number3
 - 1.2 Release History3
 - 1.3 Version Mapping Table.....4
 - 1.4 Feature and Change Description5
 - 1.1 Upgrade Overview5
 - 1.1.1 Version Upgrade Environment.....5
 - 1.1.2 Version Upgrade Modes.....6
 - 1.2 Upgrade Procedure6
 - 1.2.1 Upgrade Through the Web6

1 Version Information

1.1 Version Number

IPC_E5101-B5012P07D1603C31
 IPC_G6101-B5010P30D1607C28
 IPC_G6102-B5013P12D1611C11
 IPC_G6102-B5013P61D1611C05
 IPC_HCMN2103-B0016P12D1611C11
 IPC_HCMN2105-B0005P12D1611C11
 IPC_Q1201-B5018P12D1611C11
 IPC_5202-F5026P12D1611C11

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_E5101-B5012P07D1603C31	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_G6101B5010P30D1607C28	NA	2017-02-27	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_G6102-B5013P12D1611C11	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_G6102-B5013P61D1611C05	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN2103-B0016P12D1611C11	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN2105-B0005P12D1611C11	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_Q1201-B5018P12D1611C11	NA	2017-02-21	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_5202-F5026P12D1611C11	NA	2017-02-21	Initial release

1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series
Series	IPC23
Models	IPC23 series: IPC2322EBR-P
Target file name	IPC_E5101-B5012P07D1603C31.zip

Product Series	IPC Series
Series	IPC31
Models	IPC31 series: IPC312SR-VPF28、IPC312SR-VPF36
Target file name	IPC_G6101-B5010P30D1607C28.zip

Product Series	IPC Series
Series	IPC21、IPC22、IPC31、IPC32、IPC36
Models	IPC21 series: IPC2122SR3-UPF40、IPC2122SR3-UPF60 IPC2122SR3-PF40-B、IPC2122SR3-PF60-B IPC2124SR3-DPF36、IPC2124SR3-DPF60
	IPC22 series: IPC2222SR5-UPF40-B、IPC2222SR5-UPF60-B
	IPC31 series: IPC314SR-DVPF28、IPC314SR-DVPF36
	IPC32 series: IPC322SR3-DVSPF28-B、IPC322SR3-DVSPF40-B IPC322ER3-DUVPF28-B、IPC322ER3-DUVPF40-B IPC324ER3-DVPF28、IPC324ER3-DVPF36、IPC324ER3-DVPF60
	IPC36 series: IPC3612ER3-PF28-B、IPC3612ER3-PF40-B、IPC3612ER3-PF60-B IPC3614SR3-DPF28、IPC3614SR3-DPF36、IPC3614SR3-DPF60
Target file name	IPC_G6102-B5013P12D1611C11.zip

Product Series	IPC Series
Series	IPC81
Models	IPC81 series: IPC814SR-DVPF16、IPC814SR-DVSPF16
Target file name	IPC_G6102-B5013P61D1611C05.zip

Product Series	IPC Series
Series	IPC62
Models	IPC62 series: IPC6222ER-X20-B、IPC6222ER-X20P-B IPC6222ER-X30-B、IPC6222ER-X30P-B
Target file name	IPC_HCMN2103-B0016P12D1611C11.zip

Product Series	IPC Series
Series	IPC56
Models	IPC56 series: IPC568E-G
Target file name	IPC_HCMN2105-B0005P12D1611C11.zip

Product Series	IPC Series
Series	IPC23、IPC26、IPC32
Models	IPC23 series: IPC2324EBR-DP、IPC2322EBR-DPZ28、IPC2324EBR-DPZ28
	IPC26 series: IPC262ER9-DUZ、IPC262EFW-DUZ
	IPC32 series: IPC3232ER3-DVZ28、IPC3232ER3-DUVZ IPC3234SR3-DVZ28、IPC3234SR-DV
Target file name	IPC_Q1201-B5018P12D1611C11.zip

Product Series	IPC Series
Series	IPC32
Models	IPC32 series: IPC3232ER-VS、IPC3232ER-DV
Target file name	IPC_5202-F5026P12D1611C11.zip

1.4 Feature and Change Description


None.

1.1 Upgrade Overview

1.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

1.1.2 Version Upgrade Modes

You can upgrade through the Web.

1.2 Upgrade Procedure

1.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade	
Upgrade File	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/> <input type="checkbox"/> Upgrade Boot Program
Device Restart	
<input type="button" value="Restart"/>	Restart the device.
<input type="checkbox"/> Enable Auto Restart	Each Day <input type="button" value="v"/> 02:00:00 <input type="button" value="L"/> <input type="button" value="OK"/>
Config Management	
<input type="button" value="Default"/>	Keep current network and user settings and restore other settings to defaults.
Importing	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/>
Exporting	C:\Users\Desktop\lftp <input type="button" value="Browse..."/> <input type="button" value="Export"/>
Diagnosis Info	
Storage Path	C:\Users\MyLocalFiles\Debug\ <input type="button" value="Browse..."/> <input type="button" value="Download"/>

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_G6101-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.