

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_G6102-B5016P21D1705C08/IPC_G6103-B0006P20D1705C08.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information.....	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table	3
1.4 Feature and Change Description	4
1.1 Upgrade Overview	4
1.1.1 Version Upgrade Environment	4
1.1.2 Version Upgrade Modes	5
1.2 Upgrade Procedure	5
1.2.1 Upgrade Through the Web	5

1 Version Information

1.1 Version Number

IPC_G6102-B5016P21D1705C08

IPC_G6103-B0006P20D1705C08

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_G6102-B5016P21D1705C08	IPC_G6102-B5015P10D1702C30	2017-09-22	Improved release

Version No.	Basic Version No.	Released On	Remarks
IPC_G6103-B0006P20D1705C08	IPC_G6103-B0005P21D1702C03	2017-09-22	Improved release

1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series
Series Models	IPC2124SR3、IPC324ER3、IPC3614SR3、IPC314SR、IPC2122SR3、IPC742SR9、IPC744SR5、IPC3612ER3、IPC322SR3、IPC2222SR5、IPC2224SR5、IPC3634ER3、IPC814SR、IPC3614LR3、IPC324LR3、IPC2124LR3
	IPC2124SR3 series: IPC2124SR3-DPF36、IPC2124SR3-DPF60、IPC2124SR3-DPF120 IPC2124SR3-DPF36-16G、IPC2124SR3-DPF60-16G、IPC2124SR3-APF40、IPC2124SR3-APF60
	IPC324ER3 series: IPC324ER3-DVPF28、IPC324ER3-DVPF36、IPC324ER3-DVPF60
	IPC3614SR3 series: IPC3614SR3-DPF28、IPC3614SR3-DPF36、IPC3614SR3-DPF60 IPC3614SR3-DPF28M、IPC3614SR3-DPF36M、IPC3614SR3-DPF60M
	IPC314SR series: IPC314SR-DVPF28、IPC314SR-DVPF36
	IPC2122SR3 series: IPC2122SR3-UPF36、IPC2122SR3-UPF40、IPC2122SR3-UPF60、IPC2122SR3-PF40-B、IPC2122SR3-PF60-B、IPC2122SR3-APF40-C、IPC2122SR3-APF60-C
	IPC742SR9 series: IPC742SR9-PZ30-32G
	IPC744SR5 series: IPC744SR5-PF40-32G、IPC744SR5-PF60-32G
	IPC3612ER3 series: IPC3612ER3-PF28-B、IPC3612ER3-PF40-B、IPC3612ER3-PF60-B
	IPC322SR3 series: IPC322SR3-DVSPF28-B、IPC322SR3-DVSPF40-B、IPC322ER3-DUVPF28-B、IPC322SR3-UVPF40-B

	IPC2222SR5 series: IPC2222SR5-UPF40-B、IPC2222SR5-UPF60-B
	IPC2224SR5 series: IPC2224SR5-PF40-B、IPC2224SR5-PF60-B、IPC2224SR5-UPF40-B、IPC2224SR5-UPF60-B
	IPC3634ER3 series: IPC3634ER3-DPZ28
	IPC814SR series: IPC814SR-DVSPF16、IPC814SR-DVPF16
	IPC3614LR3 series: IPC3614LR3-PF28、IPC3614LR3-PF40
	IPC324LR3 series: IPC324LR3-VSPF28、IPC324LR3-VSPF40
	IPC2124LR3 series: IPC2124LR3-PF40、IPC2124LR3-PF60
Target file name	IPC_G6102-B5016P21D1705C08.zip

Product Series	IPC Series
Series	IPC2122SR3、IPC322SR3、IPC3612ER3、IPC2322EBR5、IPC3232ER、IPC3632ER3、IPC2124SR3、IPC312SR、IPC322ER3
Models	IPC2122SR3 series: IPC2122SR3-PF40-C、IPC2122SR3-PF60-C、IPC2122SR3-UPF40-C、IPC2122SR3-UPF60-C、IPC2122SR3-APF40-C、IPC2122SR3-APF60-C
	IPC322SR3 series: IPC322SR3-VSPF28-C、IPC322SR3-VSPF40-C、IPC322SR3-DVPF28-C、IPC322SR3-DVPF40-C
	IPC3612ER3 series: IPC3612ER3-PF28-C、IPC3612ER3-PF40-C、IPC3612ER3-PF28M-C、IPC3612ER3-PF40M-C
	IPC2322EBR series: IPC2322EBR5-P-C、IPC2322EBR5-DPZ28-C
	IPC3232ER series: IPC3232ER-VS-C、IPC3232ER-DV-C、IPC3232ER3-DVZ28-C
	IPC3632ER3 series: IPC3632ER3-DPZ28-C
	IPC2124SR3 series: IPC2124SR3-APF40、IPC2124SR3-APF60
	IPC322ER3 series: IPC322ER3-DUVPF28-C、IPC322ER3-DUVPF40-C
	IPC312SR series: IPC312SR-VPF28-C、IPC312SR-VPF40-C
Target file name	IPC_G6103-B0006P20D1705C08.zip

1.4 Feature and Change Description


None.

1.1 Upgrade Overview

1.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

1.1.2 Version Upgrade Modes

You can upgrade through the Web.

1.2 Upgrade Procedure

1.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade	
Upgrade File	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/> <input type="checkbox"/> Upgrade Boot Program
Device Restart	
<input type="button" value="Restart"/>	Restart the device.
<input type="checkbox"/> Enable Auto Restart	Each Day <input type="button" value="v"/> 02:00:00 <input type="button" value="L"/> <input type="button" value="OK"/>
Config Management	
<input type="button" value="Default"/>	Keep current network and user settings and restore other settings to defaults.
Importing	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/>
Exporting	C:\Users\Desktop\lftp <input type="button" value="Browse..."/> <input type="button" value="Export"/>
Diagnosis Info	
Storage Path	C:\Users\MyLocalFiles\Debug\ <input type="button" value="Browse..."/> <input type="button" value="Download"/>

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_G6102-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.